2 - LOADING BB'S

To load BB's, locate the BB's loading port found on the top front section of the magazine. BB's can be loaded either manually by hand or by using a specifically designed BB loader. Continue to load BB's into the loading port until you experience some resistance in loading more. Once no more BB's can be pushed down, your magazine is full. Excessively forcing more BB's in will only cause damage to your magazine or your BB loader.

With a full magazine, you can now insert your magazine into the magazine well of your rifle.

Prepare to fire your gun by removing the gun from the "safe" position to the semi or auto position. Ensure you are aiming at a safe target and press the trigger to fire a BB. In semi-automatic mode, a BB will fire with every trigger pull. On full automatic, BB's will fire continuously until the shooters finger releases the trigger. When not firing the rifle, always place the gun on safe. Remove the magazine by pressing the magazine catch and ensure there is not a BB loaded